

N-E Color Panel DMX Profile Mode 1 (24 Channel)

DMX Channel	Function	Description	Value
1	LED Color	Red 1st segment	0-255
2	LED Color	Green 1st segment	0-255
3	LED Color	Blue 1st segment	0-255
4	LED Color	Red 2nd segment	0-255
5	LED Color	Green 2nd segment	0-255
6	LED Color	Blue 2nd segment	0-255
7	LED Color	Red 3rd segment	0-255
8	LED Color	Green 3rd segment	0-255
9	LED Color	Blue 3rd segment	0-255
10	LED Color	Red 4th segment	0-255
11	LED Color	Green 4th segment	0-255
12	LED Color	Blue 4th segment	0-255
13	LED Color	Red 5th segment	0-255
14	LED Color	Green 5th segment	0-255
15	LED Color	Blue 5th segment	0-255
16	LED Color	Red 6th segment	0-255
17	LED Color	Green 6th segment	0-255
18	LED Color	Blue 6th segment	0-255
19	LED Color	Red 7th segment	0-255
20	LED Color	Green 7th segment	0-255
21	LED Color	Blue 7th segment	0-255
22	LED Color	Red 8th segment	0-255
23	LED Color	Green 8th segment	0-255
24	LED Color	Blue 8th segment	0-255

N-E Color Panel DMX Profile Mode 2 (13 Channel)

DMX Channel	Function	Description	Value
1	Strobe, Macro	No function	0-3
		Strobe (slow to fast)	4-39
		No Function	40-69
		Color Snaps (slow to fast)	70-99
		Chace RGY (slow to fast)	100-110
		Chace swirl (slow to fast)	111-121
		Chace squares (slow to fast)	122-132
		Chace sweep (slow to fast)	133-143
		Chace single sweep (slow to fast)	144-154
		Chace single sweep W/back (slow to fast)	155-165
		Chace red, cyan (slow to fast)	166-176
		Chace green, magenta (slow to fast)	177-187
		Chace purple, yellow	188-198
Red macro	199-209		
Red, cyan macro	210-220		
Cyan macro	221-231		

DMX Channel	Function	Description	Value
1	Strobe, Macro	Cyan, red macro	232-242
		Rainbow macro	243-248
		Sound strobe	249-255
2	LED Color	Red 1st segment	0-255
3	LED Color	Green 1st segment	0-255
4	LED Color	Blue 1st segment	0-255
5	LED Color	Red 2nd segment	0-255
6	LED Color	Green 2nd segment	0-255
7	LED Color	Blue 2nd segment	0-255
8	LED Color	Red 3rd segment	0-255
9	LED Color	Green 3rd segment	0-255
10	LED Color	Blue 3rd segment	0-255
11	LED Color	Red 4th segment	0-255
12	LED Color	Green 4th segment	0-255
13	LED Color	Blue 4th segment	0-255

N-E Color Panel DMX Profile Mode 3 (4 Channel)

DMX Channel	Function	Description	Value
1	Strobe, Macro	No function	0-3
		Strobe (slow to fast)	4-39
		No Function	40-69
		Color Snaps (slow to fast)	70-99
		Chace RGY (slow to fast)	100-110
		Chace swirl (slow to fast)	111-121
		Chace squares (slow to fast)	122-132
		Chace sweep (slow to fast)	133-143
		Chace single sweep (slow to fast)	144-154
		Chace single sweep W/back (slow to fast)	155-165
		Chace red, cyan (slow to fast)	166-176
		Chace green, magenta (slow to fast)	177-187
		Chace purple, yellow	188-198
		Red macro	199-209
		Red, cyan macro	210-220
		Cyan macro	221-231
		Cyan, red macro	232-242
Rainbow macro	243-248		
Sound strobe	249-255		
2	LED Color	Red all segment	0-255
3	LED Color	Green all segment	0-255
4	LED Color	Blue all segment	0-255