

N-E Color Par 1W DMX profile

DMX Channel	Function	Description	Value
1	Dimmer	Dimmer from off to full	0-255
2	LED Color	Red LED (0-100%)	0-255
3	LED Color	Green LED (0-100%)	0-255
4	LED Color	Blue LED (0-100%)	0-255
5	Strobe	No Function	0-9
		Strobe (slow to fast)	10-57
		No Function	58-59
		Pulse (on to off)	60-108
		No Function	109
		Pulse (off to on)	110-157
		Random Strobe (slow to fast)	158-255
6	Macro	No Function	0-9
		Color Fade	10-50
		Color Fade RGB	51-91
		Color Fade on to off	92-132
		Color Snap (slow to fast)	133-173
		Color Snap Random	174-214
		Random Color (slow to fast)	215-255